


# Apollo Mini Switch Monitor (55000-760) Firebeam PLUS Installation Guide



This information is provided to help the fire system designer and/or installer achieve a successful fire system installation but recommends that advice is taken from the relevant manufacturers to ensure all supporting panels and equipment used with these drawings are compatible. The relevant local Codes of Practice and legislation must be followed and take precedence over any information made or implied. The Firebeam Company does not take responsibility for the installation, commissioning or maintenance of the fire system.